

LUSTER Maintenance System

Description

LUSTER Pads are formulated to provide the user with a beautiful, durable floor and an easy, economical way to maintain a polished concrete floor using a Pacific Floorcare auto scrubber and in-house personnel. The LUSTER Pad System consists of a unique daily maintenance pad and 3-step floor repair pads. The LUSTER Pad has an advanced composite abrasive set on a synthetic fiber pad, which allows the user to maintain a highly refined floor without ongoing stock removal. LUSTER Pads are designed for use under auto scrubbers and swing machines.

Features & Benefits

- Easy to use system for daily maintenance and floor repair
- Highly efficient and economical
- When used with daily cleaner, the Daily Maintenance Pad, LUSTER DMP, will maintain and improve the DOI (Distinctness of Image) or clarity of a concrete floor
- The LUSTER DMP will not degrade the floor, keep it looking clean and shiny while remaining slip-free. This is exactly what most facilities are looking for.
- The floor repair pads are as easy to use as 1-2-3

Note: When installing LUSTER pads on equipment, the abrasive side of the pad is the work surface that contacts the floor

Uses

The LUSTER Maintenance Pad System is engineered to work on concrete and terrazzo floors with no topical coating that are either protected by non-film-forming impregnating stain protection agents or not.

Daily Maintenance

1. Sweep or dry mop the floor prior to running machines to remove any large objects that may damage equipment.
2. Install LUSTER DMP on auto scrubber with the abrasive side facing the floor.
3. Fill the auto scrubber fill tank with a daily cleaner
4. Clean the entire area moving at roughly the equivalent of walking speed

For best results, and to maintain clarity of the floor, it is recommended that the LUSTER DMP be used on an auto scrubber daily or a minimum of 5 times per week.

Floor Repair

When floor repair is required, it is recommended to use the LUSTER Maintenance Pad System (coarse, medium & fine) on a swing machine. An auto scrubber can be used as long as the pad pressure is high enough to work effectively. These pads should be **run wet** only.

Testing

1. Start with a small test area to determine the best approach depending on the condition of the floor
2. Run LUSTER 3 (FINE) with a minimum of 6 to 10 passes. Clean and let dry
3. If the surface still looks dull and damaged, take another small area and begin with LUSTER 2 (MEDIUM) followed by LUSTER 3 (FINE)
4. If the desired results are still not there, in another small area begin with LUSTER 1 (COURSE) followed by LUSTER 2 (MEDIUM) and then LUSTER 3 (FINE).

NOTE: For each step do a minimum of 6 to 10 passes, remove slurry water, then let dry. Rinse and clean pads after each step.

LUSTR Maintenance System

Repair

Once the required steps are determined from testing, begin the repair.

1. Each step should be a minimum of 6 to 10 passes
2. Overlap each pass by ½
3. Before each pad change, remove all the slurry water and let the floor dry
4. Check the dry floor to make sure all areas are uniform in appearance
5. When uniform in appearance, move on to the next pad.
6. Rinse and clean pads after each step

NOTE: After the last step (LUSTR 3 (FINE)), it is recommended that an impregnating sealer be applied.

Upon completion of the process, the repaired area along with the rest of the floor can be maintained daily with the LUSTR DMP (daily maintenance pad) under an auto scrubber.

Cleanup

After completing an application using LUSTR DMP and LUSTR repair pads, thoroughly rinse and clean each pad. Hang or stand on edge to dry and store appropriately.

Packaging Specifications

Product #	Description	Pack
LUSTR14P1	LUSTR #1 3.5" Ring Pad 14"	2 pack
LUSTR14P2	LUSTR #2 3.5" Ring Pad 14"	2 pack
LUSTR14P3	LUSTR #3 3.5" Ring Pad 14"	2 pack
LUSTR14PDMP	LUSTR 3.5" Daily Maintenance Pad 14"	2 pack

LUSTR16P1	LUSTR #1 3.5" Ring Pad 16"	2 pack
LUSTR16P2	LUSTR #2 3.5" Ring Pad 16"	2 pack
LUSTR16P3	LUSTR #3 3.5" Ring Pad 16"	2 pack
LUSTR16PDMP	LUSTR 3.5" Daily Maintenance Pad 16"	2 pack
LUSTR17P1	LUSTR #1 3.5" Ring Pad 17"	2 pack
LUSTR17P2	LUSTR #2 3.5" Ring Pad 17"	2 pack
LUSTR17P3	LUSTR #3 3.5" Ring Pad 17"	2 pack
LUSTR17PDMP	LUSTR 3.5" Daily Maintenance Pad 17"	2 pack
LUSTR20P1	LUSTR #1 4.0" Ring Pad 20"	2 pack
LUSTR20P2	LUSTR #2 4.0" Ring Pad 20"	2 pack
LUSTR20P3	LUSTR #3 4.0" Ring Pad 20"	2 pack
LUSTR20PDMP	LUSTR 4.0" Daily Maintenance Pad 20"	2 pack

Product Picture



LUSTR Maintenance System

Warning

1. Use the recommended procedures and equipment
2. DO NOT allow use by untrained operators
3. Always follow standard safety practices and wear appropriate protective equipment.

Warranty

This information is based on laboratory testing and results. Because of variations in methods, conditions and equipment, each user must test this product to make a judgment of effectiveness and performance. The product warranty obligation is limited to the refund of purchase price or replacement of the product if proven to be defective. Claims must be made in writing and received within one year from the date of product sale to the original buyer. Sole remedy shall be the replacement of the product proven defective.